

- Please read the instructions carefully before using for the first time and keep them.
 - Keep children and animals away from the packaging materials. Suffocating danger!
 - Make sure that all components, screws and bolt nuts are tight and not loose.
 - Check whether the wheel and bearings of the hoverkart are damaged. If yes, please contact us and we will send you a new product or spare part immediately.
 - Pay attention to the speed limit and keep it!
 - Misuse of the hoverkart can endanger users and people around them.
 - Do not use the seat scooter on steep slopes or on uneven terrain.
 - Under no circumstances do not make any adjustments or changes to ensure your
-
- The seat scooter may only be used in accordance with the operating instructions.
 - Misuse of the hoverkart can lead to serious injuries or even death.
 - Check the hoverkart regularly for damage and wear. The worn or damaged parts should be replaced immediately.
 - The hoverkart must not be used if it is damaged.
 - Before using the device, it is recommended that you learn how to use the hoverkart correctly. If you are not sure, please contact an experienced person or find out more on the Internet.
 - **DANGER! The hoverkart may not be used on traffic routes, sidewalks or other public places. Be careful not to break any local laws regarding the use of these types of accessories in public areas. If you are not sure, contact your local authorities.**
 - The seat scooter may only be used by one person at a time.
 - Never use the seat scooter in the dark or when the visibility is poor.
 - It is recommended to wear protective clothing (knee pads, elbow pads, wrist pads) and a helmet, ideally with neck protection.
 - Use a hair band if you have long hair.
 - The hoverkart is intended for private use and not for commercial use.
 - Never let small children play with the hoverkart. Use is recommended for children aged 6 and over under supervision.
 - The hoverkart is not intended for elderly people or pregnant women.
 - Do not use the seat scooter under the influence of alcohol or medication.
 - Do not transport loads with the seat scooter.
 - In a group of hoverkarts, keep a safe distance from each other to avoid collisions.
 - Under no circumstances should you make a phone call or listen to music while you are on the hoverkart to avoid an accident.
 - Make sure that you do not use the hoverkart on slippery or wet surfaces! It should not be used on snowy or icy surfaces.



1. Handlebar grip
2. Seat shell
3. Universal bracket
4. Rear frame with seat bracket
5. Adjustment Knob
6. Base rod steering
7. Front frame with foot support
8. Front wheel

Make sure that all brackets and attachments are in perfect condition. Do not use the hoverkart if it is defective. Use only suitable spare parts. Contact us on support@securiapro.com if you need any help!

Assembly

To properly assemble the seat scooter, please proceed as follows:

1. Open the packaging, remove all parts and check the completeness.
2. Place the seat on the frame and fasten it with the four M8 * 20 mm screws (2 in the parts list) and the matching M8 flange nuts (3). Use the Allen key (8) to tighten the screws and the open-end wrench (5) for the bolt nuts.
3. To fasten the control lever, please use the locking screws (4) and the open-ended wrench (7).



4. Set the desired length (comfortable and safe sitting position) and secure the tube with the quick release / button (6)



5. Adjust the hoverkart mount to the size of your board and secure the setting with the screws. Use the open-end wrench (5) for this purpose. Now fix the board with the supplied fabric straps with Velcro. Make sure that the hoverkart is held securely. The hoverkart use only when it is firmly attached to your hoverboard.



Cleaning and Storage

The hoverkart clean only with a damp cloth and, if necessary with a mild cleaning gent. Store the hoverkart in a dry place.

Disposal Consideration

Material recycling helps to reduce the consumption of raw materials. Pay attention to the correct disposal of scrap metal. For more information about recycling this product, please contact your municipality.

Customer Service

We want to offer you a great service. Therefore in case of defective product we will replace it with new one imidiately. In our warehouse we store all spare parts of hoverkarts for case of wear or damage. Please contact us if you need help. Email support@securiapro.com

Driving

Before every drive, please check that all screws are tight and that the hoverkart is not damaged. Do not switch on the hoverboard until you are safely seated on the hoverkart.




BRAKES:

Keep both levers in a horizontal position.

REVERSE GEAR:

Pull up on both levers to move backwards. Pay attention to your surroundings.



FORWARD:

Evenly press down on the levers to move forward.



TURN LEFT :

Press the right grip down and pull the left grip up.



TURN RIGHT :

Press down on the left grip and pull up on the right grip.

While driving, always pay attention to your surroundings and drive at a suitable speed. Never exceed the recommended maximum speed of 10 km/h. Avoid jerky steering movements. Always try to operate the controls calmly and evenly. Always be ready to brake.

Please do not drive continuously at the maximum speed of the hoverkart. Do not drive on slippery, wet or frozen surfaces. Avoid steep terrain and slopes. Always take turns carefully and steadily.

Only use the hoverkart on level surfaces, avoid holes, grooves and curbs. Do not drive over loose materials such as Branches, stones, grass or sand.

The hoverkart use only with suitable hoverboards. Before using it, make sure that you have understood all the instructions.